



Moxi Roller Skates Sizing Chart

In order to get a good fit take your most accurate shoe size and compare it to the chart. Moxi Ivy Skates run one full size smaller than your shoe size. Moxi Lolly Skates are two sizes smaller than your shoe size. "What about half sizes?" ...you may ask. Well, Moxi Skates only come in full sizes. So, take your shoe size, follow the directions, and round up or down to the nearest whole size depending on your fit preference.

Skates should fit snug at first and will conform to your foot as time goes on. Keep in mind that everyone is different, you know how you like your shoes to fit i.e. loose or snug, and should take that into consideration when purchasing your skates.

Keep on "Keepin' it Wheel!"

-Moxi xoxo

US SHOE SIZE	EU	IVY SKATE	LOLLY SKATE
5	36	4	
6	37	5	4
7	38	6	5
8	39	7	6
9	40	8	7
10	41	9	8
11	42	10	9
12	43		10
13	44		11